

## Technical Service Bulletin 030618

### LCD Screen Adjustment: IOX/DCX

This bulletin provides photos showing the adjustment of the LCD screen contrast for the IOX/DCX HPA controller. The HPA controller front panel must be pulled down to gain access to the adjustment potentiometer on the rear face of the panel (approximately behind the CLEAR button). A “trimmer” screwdriver was cut in half to make the adjustment show here.



At Comark, we are constantly striving to improve the satisfaction of both our new and existing customers. Please do not hesitate to contact Comark Customer Service with any questions you may have concerning the contents of this service bulletin.

Comark Communications LLC  
104 Feeding Hills Road  
Southwick, MA 01077 U.S.A.